

Brookstone®

UPSIDE DOWN CLOCK

CONGRATULATIONS! You now own a **top-quality Brookstone product**—thoroughly tested to be certain it meets our own **exacting quality control standards.**

Please take a few moments to review the following **important information** before using this item.

Thank You!



BEFORE YOU BEGIN

Please note that this product contains a ball bearing that allows the functions to change as the clock is rotated. This bearing moves inside the clock in order for it to function and may produce a slight rattling sound.

SETTING THE TIME/YEAR/MONTH/DAY

SETTING TIME

1. Turn the clock to the Date/Time side (this is your local time at home) and press the SET button on the back of clock. Seconds digits will flash. Press the ARROW button to set seconds.
2. Press the SET button again. Hour digits will flash. Press ARROW button to set hour. Press MODE button to exit TIME SET mode.

SETTING YEAR

1. After setting the hour, press SET button twice to activate YEAR mode. YEAR digits will flash. Press ARROW button to select YEAR.

SETTING MONTH

1. After setting the year, press SET button once. MONTH digit will flash. Press ARROW button to select MONTH.
2. Press SET button again to exit SET mode.

NOTE: Day of Week indicator in lower right corner of display adjusts automatically when setting YEAR/MONTH.

SETTING ALARM

1. Turn clock to Date/Time side. Press MODE button. ALARM display appears.
2. Press SET button to select hours field. Hour digits flash. Press ARROW button to set hour.
3. Press SET button again to select minutes field. Minute digits flash. Press ARROW button to set minutes.
4. Press MODE button to exit ALARM and return to Date/Time. The icon will show on Date/Time display to indicate that alarm function is activated.
5. To deactivate alarm, press MODE button to display alarm function and press ARROW button to deactivate alarm. The icon will disappear on Date/Time display indicating alarm is off.

TURNING OFF ALARM SOUND

To turn off alarm, press **MODE** button after alarm has begun beeping.

SELECTING AM/PM

To select AM/PM on alarm, cycle through the first 12 hours by pressing the **ARROW** button until PM indicator appears on display. If no AM/PM indicator is showing, the clock is in AM mode.

THERMOMETER

The thermometer function works automatically when the clock is rotated to the Thermometer side. To select Centigrade or Fahrenheit, simply press the **ARROW** button.

TIMER

The TIMER activates automatically when you rotate the clock to that side. To stop/start TIMER, press SET button. To reset TIMER, press ARROW button.

WORLD TIME FUNCTION

Rotate clock to World Time side. Turn the 16-time zone dial located on back of clock to the time zone you want. The time will automatically appear in the display.

SETTING DAYLIGHT SAVINGS TIME

Make sure the "World Time" side is positioned up.

1. Press "MODE" button once - hour will advance to indicate Daylight Savings Time - SUMMER will be displayed on the screen.

2. Press "MODE" button once again to return back to Standard Time - SUMMER will no longer be displayed on the screen.

NOTE: In "World Time" mode, when the "SET" button is pressed, the local time zone will be set up as the World Time zone that you adjusted.

CHANGING BATTERY

1. If display is unclear or all four functions show simultaneously on display, the battery needs replacing.
2. To replace battery (not included), unscrew battery cover on back of unit and insert a new AAA battery (not included) observing proper polarity +/- as indicated in compartment.

Brookstone®

Nashua, New Hampshire 03062

Customer Service 800-846-3000

350165